

## Instruction to turn on your solar system

To make your solar system function, the system has to be turned on. Please confirm the bi-directional meter is in place and then follow the instruction below to ensure your system is working properly. Feel free to contact us if you are not comfortable doing this.

### 1. Turn on the breakers in your main service panel

This panel is usually located in either your basement or your garage. Please check if the breakers are on and turn them on if not. See the picture below for your reference.



**2. Turn on the combiner box and disconnect if applicable**

These are outside of your house beside your meter. Please refer to the picture below.

If you have a small solar system, there is only one box. Please make sure the breakers in this box are turned on.

If you have a big solar system, you will see two boxes as shown in the picture below. Please make sure the breakers and switches are turned on in both boxes.

